

# ADA Shower Curtain



- Patented design with weighted curtain bottom, 4" lip and velcro sides seals curtain to wall, preventing water from leaking out of shower stall
- Specially formulated Super Bio Stat protective coating is mildew, bacterial and wear resistant
- Curtains have been tested and pass fire safety standards

IPC.534/REV.5

# ADA Shower Curtain Suggested Specifications

---

## PART 1 GENERAL

### 1.01 SUMMARY

A. Shower Curtain

### 1.02 SECTIONS INCLUDES

A. Water Stopping Shower Curtain

### 1.03 REFERENCES

A. National Fire Protection Association (NFPA)

### 1.04 SYSTEM DESCRIPTION

A. Performance Requirements: Provide curtains that conform to the following requirements of regulatory agencies and the quality control of Clickeze Privacy Systems™, InPro Corporation.

1. Fire Performance Characteristics: Provide curtains that conform with NFPA701, fire test for flame and resistant textiles and films.

### 1.05 SUBMITTALS

A. Product Data: Manufacturer's printed product data for each type of curtain specified.

B. Fabric Samples: Swatch cards of fabric samples illustrating fabric color and weave.

C. Manufacturer's Care Instructions: Printed care instructions for each curtain.

### 1.06 DELIVERY, STORAGE AND HANDLING

A. Deliver materials in unopened factory packaging to the jobsite.

B. Inspect materials at delivery to assure that specified products have been received.

C. Store in original packaging in a climate controlled location away from direct sunlight.

### 1.07 PROJECT CONDITIONS

A. Environmental Requirements: Products must be installed in an interior climate controlled environment.

### 1.08 WARRANTY

A. Standard Clickeze Limited Lifetime Warranty against material and manufacturing defects.

## PART 2 - PRODUCTS

### 2.01 MANUFACTURER

A. Acceptable Manufacturer Clickeze Privacy Systems™, InPro Corp. PO Box 406 Muskego, WI 53150 USA  
Telephone: 800.222.5556, Fax: 888.715.8407,  
www.inprocorp.com

B. Substitutions: Not permitted

C. Provide all privacy curtains from a single source.

### 2.02 MATERIALS

A. ADA Shower Curtain

1. Vinyl Material: Provide heavy duty, 13 gauge, flame retardant, anti-microbial vinyl that is water repellent, wear resistant, scrubbable and colorfast.

### 2.03 FINISH AND COLOR

A. Shower Curtain Vinyl: Select solid or patterned opaque material or light transmitting vinyl from manufacturer's standard selection.

### 2.04 FABRICATION

A. ADA Shower Curtain

1. Width: Manufacture ADA Shower Curtain of one piece, sized in width to the next increment of 6".

2. Height: Height to be from bottom of curtain hooks or rings to the floor.

3. Heading: Include 4-ounce nickel-plated grommets, 3-1/2" from each end and 6" on center for carriers. ADA Shower Curtain curtain top hem to be triple-turned hem over nylon tape for rugged wear.

4. Water Dam: Provide 3" mitered corner to achieve 3" dam.

5. Seams: ADA Shower Curtain is to be seamless with sanitary "no scum" side and bottom edges. Sewing thread to be triple ply twisted nylon.

6. Velcro: Provide 4" x 3" side sealing Velcro. Each side of curtain shall have three rectangles of loop Velcro sewn 1" below top hem, 2" above weight pocket and 36" above the bottom of curtain.

7. Weights: Provide curtains with 1-1/4" weight tape sewn into bottom hem. Weights per yard - 22.

## PART 3 - EXECUTION

### 3.01 EXAMINATION

A. Examine areas and conditions in which privacy tracking system will be installed.

1. Complete all finishing operations, including painting, before beginning installation of privacy tracking system materials.

2. Verify that surfaces and above ceiling supports are ready to receive work.

### 3.02 PREPARATION

A. General: Prior to installation, clean substrate to remove dust, debris and loose particles.

### 3.03 INSTALLATION

1. Install curtain track, secure, rigid, and true to ceiling line or use existing curtain rod.

2. Slide carriers onto the track or use existing curtain hooks.

3. Install end cap or stop device as required.

4. Secure or suspend track to ceiling system. Install with mechanical fasteners or Gridclips.

5. Install curtains on carriers ensuring smooth operation.

6. Position each edge of the curtain against the wall keeping it plumb and in line with the track. Mark the location of each Velcro pad. Within the marked area, apply a continuous 1/8" x 3/16" (approx.) bead of Dow-Corning 732 Clear Sealant in the shape of a rectangle. (Illustration: show rectangular bead of adhesive that is 1/8" away from the perimeter of Velcro) Remove the release liner from the Velcro. Press the Velcro to the wall. Smooth out the Velcro by hand. Allow sealant to cure for 24 hours prior to any contact with water or engagement with mating Velcro.

7. To access the shower compartment disengage the Velcro by sliding fingers into the Velcro pocket on the curtain.

### 3.04 CLEANING

A. At completion of the installation, remove any debris and clean surfaces in accordance with the Clickeze clean-up and maintenance instructions.