

# Clickeze® Clean-up and Maintenance:

## Cubicle Track, Curtains, and Soft Goods

---

### Cubicle Tracks

Cubicle tracks require very little maintenance. If carriers do not move smoothly, check the track for binding. If the track is clear of debris, spray the inside of the track with a light coating of silicone spray. Be careful not to spray the curtains and wipe any excess spray from the track.

### Standard Cubicle Curtains, Cubicle Curtain Mesh or Standard Fabric Only

1. Wash Cycle: Wash as any standard colored fabric, with water temperature not to exceed 160°F. Detergents: Use a synthetic detergent. DO NOT use a caustic soap or bleach. Do Not add softener.
2. Extraction Cycle: Fabric requires no more than 2-4 minutes extracting, depending on size of load and equipment used.
3. Drying Cycle: Tumble dry for 3-5 minutes on the low/synthetic cycle. DO NOT overload the dryer. Excessive heat will decrease the permanent press feature of this fabric. Remove immediately from the dryer after the cycle is complete.
4. DO NOT put through a mangle.

### Draperies/Top Treatments

Draperies should be cleaned as seldom as possible with dusting or vacuuming done on an "as needed" basis. Frequent or repeated cleanings may remove some of the "life" from a drape eventually yielding limpness to the material. Dry cleaning is the preferred method for cleaning.

### Decorative Metal Drapery Rods

To clean the rods, wipe them with a damp cloth.

### Vinyl Shower Curtain Washing Instructions

Super Bio Stat materials offer "clean-in-place" convenience. Any soils or stains that may accumulate on the surfaces should be removed periodically for a fresh new appearance. Use neutral soap suds and lukewarm water. Then rinse with water and allow fabric to dry. Hard to Clean Spots: Standard household/vinyl cleansers and/or a soft bristle brush can be used for removing troublesome spots or stains. Heavy "dried on" soil may first require soaking to loosen. DO NOT USE HARSH CLEANSERS OR SOLVENTS.

Inpro Corporation does not recommend the laundering of Super Bio Stat since laundering may substantially decrease the useful life of these fabrics. However, if laundering is required, follow the procedures of the International Fabricare Institute:

1. Wash and rinse according to the "Synthetic Washing Procedure for Coated Fabrics" with temperatures not exceeding 100° F.
2. Extract water with centrifugal extractor.
3. Tumble dry in a steam dryer (not gas) at 120° F. maximum. For tailored, precise fitted items, tumble dry without heat or air dry. DO NOT IRON.

### Bedspreads/Bed Scarves

1. Wash separately (do not combine with other products)
2. Wash darks separately
3. Machine wash (120° F - 160° F)
4. Tumble dry – medium – remove promptly
5. Use steam iron – low setting
6. DO NOT DRY CLEAN  
2-3% shrinkage anticipated in washing cycle

IPC.532/Rev.17