

WebbGlide and WebbLok Cleaning Instructions

Entire shade system may be cleaned while installed in the window.

General Fabrics

You may use alcohol, solvent*, citrus or bleach based cleaners on any non-printed fabrics. Avoid using non-diluted bleach as, over time, this may compromise the anti-microbial properties of the fabric. When in doubt, we recommend spot testing an inconspicuous area before using a cleaning agent over the entire shade.

**Acetone based solvents, as are used in dry cleaning, are not recommended.*

Custom Printed Fabrics*

We recommend using a mild soap and water mixture applied with a non-abrasive sponge or cloth. You may use any type of disinfectant or cleanser as long as you do not use any of the following:

- ◆ DO NOT USE alcohol or solvent based cleaners
- ◆ DO NOT USE any citrus based cleaners
- ◆ DO NOT USE any abrasive materials

Use of materials listed above will result in the printed pattern being removed from the fabric and will void the WebbShade 3 year fabric warranty. As a suggestion, if in doubt, spot test an inconspicuous section of the material before wiping the entire shade with cleaner.

**Also applies to Vertilux Noche Blackout fabrics.*

Hardware

Guide tracks may be lightly sprayed (inside) using silicone lubricant only.
(Never use petroleum based lubricant.)

Baked on powder coat will not be harmed by any cleaning agents as it can only be mechanically removed.

IPC.2123/REV.1

Installation Hotline • 866.EZINPRO
Inprocorp.com • 800.222.5556 • 262.679.9010
World Headquarters S80 W18766 Apollo Drive, Muskego, WI 53150 USA

CLICKEZE® •
PRIVACY SYSTEMS
A DIVISION OF INPRO®